

Bluetooth Pairing

1. Set switch on the back of the keyboard to the “Bluetooth Icon” position.
2. The keyboard can support Bluetooth connections for up to 3 devices. Press FN+Q/W/E (keyboard switches lighting will blink once and notification led will blink thrice) then select and set up a connection to pair a new device
3. Press and hold FN+P for 3-5 seconds, the “P” key LED will begin to flash repeatedly to indicate that the keyboard is ready to connect to a new device over Bluetooth .
4. On the device you wish to connect to, begin to search for Bluetooth devices and select “RAKK PLUMA” once it appears on the device.
5. Once the keyboard has connected to the device, the “P” key will stop flashing to indicate successful Bluetooth pairing.
6. Press FN+Q/W/E to switch to a previously paired device on the saved profile.

Charging

1. “Fn” key backlight LED will flash white repeatedly when keyboard battery power is low.
2. The second indicator LED will light up to red while battery is charging.
3. Once the battery has been fully charged, the second indicator LED will shut off.
4. Backlights will automatically shut off after 5 minutes without use. After 30 minutes without use, the keyboard will enter standby mode and disconnect from Bluetooth. Press any key to wake the keyboard and resume use.





Backlight Settings

- FN+INS/DEL: Switch backlight modes, Each key has 9 different modes for a total of 18 backlights modes.
- FN+DEL : Static, Single-on, Single-off. Rotate, Scroll, Roll, Fall, Colorful, Glitter
- FN+INS : Ripples, Explode, Launch, Breath, Outward, Spectrum, Pulsate, Flow, Tilt

Backlight Macro Recording:

1. Press Fn+Z/X/C. Each key can store one backlight mode macro.
2. Press Fn+Tab. The Ctrl, Caps, and Windows keys will flash repeatedly to indicate that backlight macro recording has begun.
3. Press the keys that you wish to set backlighting for.
4. Press Fn+ Tab again to stop backlight macro recording. The Caps keys will stop flashing and custom backlight settings will be saved to the chosen profile.

Backlight Control

- FN+PG UP = Increase backlight brightness
- FN+PG DN = Decrease backlight brightness
- FN+ = Decrease backlight speed
- FN+ = Increase backlight speed
- FN+ = Switch dynamic backlight direction
- FN+ = Switch color of the backlight

The LED indicators will flash 3 times when backlight running fastest /slowest and highest/lowest light brightness.

- FN+A = WIN OS
- FN+S = MAC OS
- FN+WIN-L = Lock & unlock Windows key
- FN+B.SPACE = Reset keyboard (hold 3 seconds)
- Fn + Z/X/C = Backlight Macro recording key
- Fn+Q/W/E = Bluetooth profiles
- FN+Tab = Macro recording and saving